

# Southern PIKNIK®

## Portable Bench Assembly



1. Position the main bench support brackets within the marked location lines on underside of seat section. Please note that the 12" contour seat section is not symmetrically shaped and has a front and rear edge.
2. Secure the seat to the main brackets with bolt clip system which is preinstalled to the brackets. The clips engage the return flanges on underside of seat section.
3. Bolt the flat bar sway braces to the front web of the main brackets and the return flange on underside of seat section through the predrilled hole.
4. Attach backrest section to the "hat section" backrest support stanchions as shown on sketch below. The 1/4" flat bar riveted to inside of top return flange secures the top of the backrest stanchion to the backrest.
5. Install the backrest assembly to the bench seat section with the bolt clip system reinstalled to the backrest support stanchions.

