

TOOLS REQUIRED:





Sh1

PHILIPS HEAD SCREWDRIVER, HAMMER (NOT PROVIDED)
HEXAGON WRENCH (PROVIDED)








- ☆ WEIGHT LIMITED: 220 LBS
- ☆ DO NOT SIT OR LEAN AGAINST ARMRESTS
- ☆ SCREWS MUST BE TIGHTENED UP BE SURE TO TIGHTEN UP THE SCREWS IN ASSEMBLY.



HARDWARE LIST

<p>(A) WOOD SCREW 6PCS</p>  <p>SIZE: 1-3/4" L PHILLIPS HEAD</p>	<p>(B) WOOD SCREW 4PCS</p>  <p>SIZE: 1-1/2" L PHILLIPS HEAD</p>	<p>(C) WOOD SCREW 2PCS</p>  <p>SIZE: 2" HEXAGON HEAD</p>	<p>(D) GLUE 2PCS</p>  <p>A&B GLUE MIX USED (RED & BLUE GLUE MIX USED)</p>
---	--	---	--

PARTS LIST


<p>1. BACK FRAME 1PC</p> 	<p>2. ARM 2PCS</p> 	<p>6. FRONT FRAME 1PC</p> 
	<p>3. SEAT FRAME 1PC</p> 	
<p>4. WOOD STICK W/HOLES 2PC</p> 	<p>7. CURVED SHAPE WOOD ROCKER 2PCS</p> 	
<p>5. WOOD STICK (NO HOLE) 4PC</p> 		

WOOD ROCKING CHAIR ASSEMBLY INSTRUCTION

Sh2

STEP 1.

LAY THE BACK FRAME(1) ON SOFT AND CLEAN SURFACE WITH HOLES FACING UPWARDS. INSERT WOOD STICKS (4) TO THE THIRD (COUNTING FROM BOTTOM TO TOP) HOLES OF THE BACK FRAME(1). BE SURE THE WIDER OPENING SCREW HOLES ON THE WOOD STICKS(4) ARE FACING DOWNWARD. THEN INSERT 4 PIECES WOOD STICKS TO THE LOWER 4 HOLES OF THE BACK FRAME. ATTACH THE FRONT FRAME(5) TO THE WOOD STICKS THAT WERE JUST INSERTED ON THE BACK FRAME. BE SURE THE NARROW END OF FRONT FRAME ARE ON THE BOTTOM OF THE ROCKER



STEP #1

STEP 2.

ATTACH THE CURVED SHAPE WOOD ROCKERS(6) TO THE BOTTOM OF BACK FRAME(1) AND FRONT FRAME(5) SCREW 4 PIECES WOOD SCREWS(A) THROUGH CURVED SHAPE WOOD ROCKERS(6) TO SECURE WOOD ROCKERS(6) ONTO BACK FRONT FRAME. PLACE SEAT(3) ONTO WOOD STICKS (4) AND SECURE BY USING WOOD SCREWS (B) THROUGH THE SCREW HOLES ON WOOD STICKS(4) TO SEAT. FOR EASIER ASSEMBLY YOU MAY NEED TO TURN WOOD STICKS(4) WITH SCREW HOLES SLIGHTLY FACING OUTWARDS IT WOULD BE DIFFICULT FOR YOU TO SCREW IF THESE SCREW HOLES ON WOOD STICKS ARE FACING DOWNWARD VERTICALLY.



STEP #2



STEP 3.

PLACE WOOD ARM ONTO THE TOP OF THE FRONT FRAME(5) AND INSERT THE OTHER END OF WOOD ARM TO THE HOLES ON THE BACK FRAME(1) SECURE WOOD ARMS TO BACK FRAME BY USING WOOD SCREWS(C). AND USING WOOD SCREWS(A) TO SECURE WOOD ARMS TO FRONT FRAME. SEE ILLUSTRATION TO ENSURE RIGHT/LEFT ARM ARE ON THE CORRECT POSITION

TIGHTEN ALL WOOD SCREWS PROPERLY BEFORE USE.

TO ADD STABILITY OF ASSEMBLING, APPLY SMALL AMOUNT OF MIXED GILK A28 TO WOOD HOLES DURING ASSEMBLING

YOUR BEAUTIFUL
WOOD ROCKER IS
FINISHED AND READY
TO USE



STEP #3